

## 施工上のご注意

このたびは KYOTO IZUMI WALLCOVERING 製品をお買い上げいただき、誠にありがとうございます。

当製品は天然素材の織物壁紙でデリケートな為、施工される際以下の点にご注意下さい。

### はじめに

3 巾施工した時点で仕上がりをご確認ください。

万が一商品に不具合が見つかった場合、直ちに施工を中止し、弊社までご連絡ください。

ご連絡をいただかないまま施工を続けられた場合、クレームをお受け出来ない場合があります。

※製造ロットにより色・柄・風合いが実際の商品とサンプルとは、多少異なる場合があります。

商品の欠点ではなく、意匠の一部としてお考えください。

### 施工方法

■必ず下地と同色のパテをご使用いただき、施工面を平滑に仕上げてください。

また施工後下地の色が透けて見えることがあります。

必要に応じてカラーシーラーをご使用になり、下地の色を統一してください。

■ベニヤなどの下地の場合、時間経過とともに変色やシミが発生する恐れがあります。

ベニヤに限らず下地に合ったシーラーなどで処理を行ってください。

(いかなる下地の場合でもシーラー処理をされることをおすすめします)

■下地は十分に乾燥させてから施工してください。剥がれや変色、カビの発生などの原因となります。

■糊は糊メーカーの規定の希釈率を必ず守ってください。原液タイプの糊の御使用をおすすめします。

■オープンタイムは 5 分から 15 分を目安とし、なるべく付け溜めは避けてください。

たたみじわの原因になりますので、糊付け後は必ず大きいたんで上積みはしないでください。

■壁紙の表面に糊が付かないようご注意ください。

■素材により糊が落ちない物、また強くこすることにより表面の色が落ちるものがあります。

■施工後は外気や冷暖房などによる急激な室温変化を避けてください。

目開きやはがれなどの原因になります。

■当製品はつきつけ施工を推奨しております。

その他、お問い合わせ等ございましたらご連絡下さい。

## HANGING INSTRUCTIONS

Thank you very much for choosing KYOTO IZUMI WALLCOVERING!

### BEFORE YOU START

Carefully inspect all materials and make certain that the pattern and color are exactly as ordered.

No claims will be accepted for cut/installed material, beyond the installation of 1 roll, or after 14 days of delivery.

You may find variations in weaving and color effects, which are considered characteristics/part of the beauty of such products, and are not defects.

### SURFACE PREPARATION

Remove all existing wallcovering, backing paper, paint, and all surface contaminations, ensure the surface is smooth and dry.

Make sure to match the color to the wall when using putty.

Apply primer/sealer and allow to dry.

### ADHESIVE

We recommend using starch based, ready mixed wallcovering adhesive.

### HANGING

Paste the back of the wallcovering, book for 5-15minutes to let adhesive penetrate the material.

Do not crease the paper when folding length, and do not pile after pasting.

Work quickly using a soft brush in vertical direction only, and gently smooth the paper onto the wall.

Joints should be tightly butted. Gently use the seam roller to finish off the joint.

Avoid excessive seam rolling, as this may cause damage.

Avoid adhesive to get onto the surface of any wallcovering. Immediately wipe off any excessive paste with soft damp cloth and then with a dry cloth. Do not rub or use sponge as it may damage the surface of wallcovering.



info@kyoto-izumi.com